



**BULLARD
BOLLARDS**
Think Bollard Think Bullard

INSTALLATION INSTRUCTION

MEGA SEGNO SPOT RD P&P


INSTALLATION TYPE:
SPOT



01/27/2026



MEGASEGNO SPOT P&P



IT Spegner l'alimentazione

EN Switch-off the power supply

FR Coupez l'alimentation électrique


DE Schalten Sie die Stromversorgung aus

ES Desconectar la alimentación



PT Desligar a fonte de alimentação

RU Отключите источник питания

AR قاطع الطاقة



1



EN

In order to preserve the environment, at the end of its life, do not throw this appliance in the normal waste collection, but take it to one of the authorised collection points.

P.2

sales@gordonbullard.com

www.bullardbollards.com

1 877-964-4646




991 South Gull Lake Dr.

Richland, MI 49083

USA



MEGASEGNO SPOT P&P



IT Spegner l'alimentazione

EN Switch-off the power supply

FR Coupez l'alimentation électrique


DE Schalten Sie die Stromversorgung aus

ES Desconectar la alimentación



PT Desligar a fonte de alimentação

RU Отключите источник питания

AR قاطع الطاقة



1



EN

In order to preserve the environment, at the end of its life, do not throw this appliance in the normal waste collection, but take it to one of the authorised collection points.

P.3

sales@gordonbullard.com

www.bullardbollards.com

1 877-964-4646



991 South Gull Lake Dr.

Richland, MI 49083

USA

IMPORTANT

- To ensure equipment safety you must carefully follow the instructions below. This leaflet must be kept handy by personnel entrusted with all ordinary and extraordinary maintenance.
- Before any installation or maintenance operation on the bulb, make sure it is disconnected from power.
- Fit the correct bulbs, according to the type and power indicated on the lamp data label.
- Make sure the lamp technical features are compatible with the use you are going to make of it.
- Should you have any doubt, refer to the dealer or ask an electrician.
- When connecting to the mains, follow the correct colour code for power cables: (N) blue, (L) brown or black and, only for class I equipment, (T) yellow/green.
- When lamps are to be fitted to the wall directly through their ceramic parts, fasten the fixing screws lightly, to avoid breaking the ceramic.
- To clean the lamp on the outside, use a soft cloth, possibly wet. Do not use solvents or abrasive products. No liquid must get in contact with the lamp interior parts.
- Do not touch the equipment with dirty hands.



= Class I equipment, must be connected to an earth terminal.




= Double insulated lamp, does not need earthing.



= Electrical equipment in class III, electrical safety guaranteed by low voltage tension, does not require grounding



= Minimum distance to be observed from all lit up objects.



= Replace immediately the safety glass, if damaged, with the original part.



= The lamp uses low pressure bulbs, and needs no protection glass.