



**BULLARD
BOLLARDS**
Think Bollard Think Bullard

INSTALLATION INSTRUCTION
01/15/2026


THE LILAS

INSTALLATION TYPE: ANCHOR MOUNT




1. EXTERIOR DETAILS


1.1 Luminaire



1.2 Dimension



1.3 Inground Base (Optional)



Data Sheet:

Input Voltage (V): 110-277

IK: 07

P.2

sales@gordonbullard.com
www.bullardbollards.com
1 877-964-4646




991 South Gull Lake Dr.
Richland, MI 49083
USA




INSTALLATION OPTION 1: Anchor Mounted


Step 1




Step 2



Step 3



Step 4



P.3

sales@gordonbullard.com
www.bullardbollards.com
1 877-964-4646




991 South Gull Lake Dr.
Richland, MI 49083
USA




INSTALLATION OPTION 2: Surface Mounted


Step 1




Step 2



Step 3



Step 4



P.4

sales@gordonbullard.com
www.bullardbollards.com
1 877-964-4646



991 South Gull Lake Dr.
Richland, MI 49083
USA

