



**BULLARD
BOLLARDS**
Think Bollard Think Bullard



BUNNY DOT


INSTALLATION TYPE:
RECESSED

DOT-115


DOT-155

DOT-233






1A




2A


If water does not disappear in 30 min. you must use a further drainage system:




or




or




3A




4A




5A



6A




1B




2B


If water does not disappear in 30 min. you must use a further drainage system:




or




or




3B




4B



5B




6B



7A-B




8A-B



9A-B



10A-B



11A-B

THE SAFETY OF THIS FIXTURE IS GUARANTEED ONLY IF YOU COMPLY WITH THESE INSTRUCTIONS; REMEMBER TO KEEP IN A SAFE PLACE. THE APPLIANCE MUST NOT BE TAMPERED WITH OR TRANSFORMED AND IT MUST BE INSTALLED AND USED AS SUPPLIED AND IN COMPLIANCE WITH THE NATIONAL RULES ON INSTALLATIONS. SWITCH-OFF THE POWER SUPPLY BEFORE CARRYING OUT ANY MAINTENANCE OPERATIONS. HOT PLUG-IN IS NOT ALLOW AND MAY CAUSE DAMAGE TO THE LUMINAIRE. THE LIGHT SOURCE CONTAINED IN THIS LUMINAIRE SHALL BE REPLACED ONLY BY THE MANUFACTURER OR HIS SERVICE AGENT. INSTALLATION AND SERVICE MUST BE PERFORMED BY QUALIFIED SERVICE PERSONNEL. ANY NON-COMPLIANT INSTALLATIONS WILL INVALIDATE ALL FORMS OF GUARANTEE.

P.4

sales@gordonbullard.com

www.bullardbollards.com

1 877-964-4646



991 South Gull Lake Dr.

Richland, MI 49083

USA