


SOCAR




Data Sheet:
Input Voltage (V): 110-277
IK 08




Installation steps


Step 1



Step 2



Step 3



P.2

sales@gordonbullard.com
www.bullardbollards.com
1 877-964-4646

991 South Gull Lake Dr.
Richland, MI 49083
USA

